

CONTAMINATION PROTOCOLS

(Tested with PQ1 and PermaQuick)

<p>1. Etch</p>	<p>(Get Back In Control) G B I C</p> 	<p>(Wash & Dry) W & D</p>	<p>(Re-Etch/Re-Apply) R-A</p>
<p>2. Prime 3. Single component 4. Bond</p>	<p>G B I C</p>	<p>W & D</p>	<p>R-A A. Primer (LC) B. Bond Resin C. Single Component (LC)</p>
<p>5. Composite</p>	<p>G B I C</p>	<p>W & D</p>	<p>APPLY STAND-ALONE BOND RESIN (COMPOSITE WETTING RESIN)</p>

*As tested for short duration procedural contamination