

Immediate Dentin Sealing "IDS"



Scour and clean



Apply Peak SE and air thin



Apply Peak LC



Air thin then gently air dry



LC all surfaces for 10 seconds



Apply PrimaDry to dissolve the O₂ layer



Wash off PrimaDry with H₂O and air dry. Make impression



Important provisional subjects:
 1. Do not form resin provisional directly against resin sealed surface! Use a separating agent. DeOx will work for this.
 2. Do not cement provisional with resin provisional cement. Ultratemp is recommended



After removing provisional:

Scour and Clean

Important definitive subjects for:

1. *Light cure resin luting: Treat the surfaces with all the usual steps. Recommend: Peak SE, air thin then Peak LC, air thin, air dry DO NOT light cure; cement with resin luting composite.*
2. *Dual/chemical cure resin luting: Treat the surfaces with all the usual steps. Recommend: Peak SE, air thin then PermaFlo Primer A then B, dry completely and lute with mixed PermaFlo DC composite resin.*

For cements e.g. GI and RMGI:

Cement as usual